



REAR GLASS STABILIZER

video install link: <https://youtu.be/M04HVtCR-AA>

1. Insert the round *eye* end of the stabilizer into the catch mechanism until it clicks/locks in as shown in pic #1. The *eye* end is a threaded bolt that could be unscrewed which allows for flexibility required to attach to vehicle and then to the glass bar. We do not recommend unscrewing it any more than is required to attach as it was designed to work best that way. To remove the stabilizer from the catch mechanism you would use the same process required for your specific vehicle to unlock the rear glass.



1



2



3

2. Separate the two rubber pieces on the *hook* end of the stabilizer and slide the bottom piece to the side. Then place the *hook* end of the stabilizer on your glass bar making sure that the top piece of the rubber fastener threads straight as shown in pic #2.
3. Slide the bottom piece of the rubber fastener around until it lines up, so you can insert the end of the *hook* through the hole in the bottom piece of rubber and then connect the two rubber pieces with the Velcro. Pic #3
4. Take the ends of the two pieces of rubber and bend them backwards through the glass bar with a slight tug... be easy as it doesn't require more than a good little tug and you don't want to damage the rubber fastener. This step is crucial to secure the fastener against the bar. Pic #4



4



5



6

5. You're done. Pic #5 (6" model) and Pic #6 (9" model). To remove, simply unfasten the bottom piece of the rubber fastener and pull it back off the hook and slide to the side and then unhook the glass bar. Remove the stabilizer from the catch mechanism the same way you would unlock the rear glass on your specific vehicle.

Two very important things:

The stabilizer is not intended to be a security device for your vehicle and could be removed from the glass bar by someone from the outside. All safety precaution should always be taken.

CAUTION: Exhaust fumes from a vehicle can be hazardous and fatal under certain conditions. All safety precaution should always be taken to make sure that the exhaust from the vehicle using the stabilizer and any vehicle in immediate proximity does not create a backflow into the vehicle and it is advised that other windows are always open/vented while venting the rear glass.

RAD RUBBER DESIGN assumes no responsibility from the use of this product.